

Exchange Parameter Monitor



It is a must to measure monitor of 2000 maintain the important of an exchange lie Exchange Earth resistance, Exchange Battery voltage, Temperature, Status of Air Conditioner etc. It is a tedious job to continuously measure and monitor which measures and display all parameter on single panel. So, the concerned officer is to see simple the front panel, come to know states of all parameter. The integration of all parameters helps to function exchange smoothly.

SPECIFICATION

•	Input Voltage
	220 V, 50 Hz, 0.5 A
•	Output Voltage
	75 Rms / 20 mA 3 ½ digit
	Voltage (AC) LED 3 digit 7 segment
	Battery Voltage LED 3 digit 7 segment
	Earth Resistance LED 4 digit 7 segment
	Exchange Batter Status / AC LEDs
	Status / Exchange Working
	Temperature LED display
•	Weight
	Light and Compact
•	Mounting
	Wall Mounting
•	Accessories
	All required accessories

FEATURES

- Integrate all important parameter on single panel.
- Need not measure any parameter.
- All parameters measures and display automatically
- The status of the parameter also displays
- Obviate the cumbersome procedure to measure earth resistance, Battery

voltage etc. each time.

-
- No human error.
 - Helps to function to BSNL/MTNL Networks smoothly.
-